



Documentation of the Command Table IO interface for the following Controllers:

- E1100-GP, E1100-GP-HC



Command Table IO Interface V3.6 User manual

NTI AG
LinMot®
Haerdlistrasse 15
CH-8957 Spreitenbach

Tel.: +41 (0)56 419 9191
Fax: +41 (0)56 419 9192
Email: office@linmot.com
Internet: www.linmot.com

© 2006 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying,

recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

Note

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation. NTI AG reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement. Please refer to the latest edition of our "General business terms"

Document version 3.6 / Feb, 2006

1	SYSTEM OVERVIEW	4
2	ACTIVATING AND DEACTIVATING OF THE COMMAND TABLE IO INTERFACE.....	4
3	SMART CONTROL WORD BEHAVIOR	5
	<i>Intf Switch On Flag Behavior.....</i>	<i>5</i>
	<i>Intf Home Flag Behavior.....</i>	<i>5</i>
	<i>Intf Error Acknowledge Flag Behavior.....</i>	<i>5</i>
	<i>Intf Go To Initial Pos Flag Behavior</i>	<i>5</i>
4	MOTION COMMAND TABLE.....	6

1 System Overview

The Command Table IO Interface SW is an easy to use SW with the following functionality:

- Smart Control Word behavior (Enable, Home and Error Acknowledge over one single IO possible)
- Mapping of the X6 inputs to access the Command Table ‘Motion Commands’
- Mapping of the X 6 outputs for system feedback of its state

All of this functionality could be wired to the X6 connector that is available on the GP servos of the E1100 series.

2 Activating and Deactivating of the Command Table IO Interface

Over the Interface Switch on the S3.4 the Command Table IO Interface SW can be activated (Switch On) or deactivated (Switch Off), like all other interface SW on The E1100 Servo Controller series.

S3

On - Off

Interface	<input type="checkbox"/>	4
CAN Term	<input type="checkbox"/>	3
RS485 Term	<input type="checkbox"/>	2
RS485/232	<input type="checkbox"/>	1

3 Smart Control Word Behavior

All Control Word actions that are configured in the EasySteps SW are done to the Interface Control Word bits. So if a Control Word bit is mapped to a X4 IO or forced by parameter this still has priority and the behaviour rests unchanged.

Intf Switch On Flag Behavior

It is strongly recommended to influence the Control Word bit 0 'Switch On' over a serial bus connection or a digital input. For a testing system it might be helpful if the systems starts up automatically of powered on, for this case the switch On could be set to autostart.

Intf Home Flag Behavior

Setting the Intf Home Flag Behavior to 'Autohome' starts automatically the homing if the state 8 'Operation Enabled' is reached and Statues Word bit 11 'Homed' is not set. Then when the homing sequence has finished the interface Control Word Bit 11 'Home' is reset and the state 8 is entered again.

Intf Error Acknowledge Flag Behavior

Setting the Intf Error Acknowledge Flag Behavior to '/Switch On Flag' sets the interface Control Word bit 7 'Error Acknowledge' when releasing the 'Switch On' Flag.

Intf Go To Initial Pos Flag Behavior

Setting the Intf Go to Initial Pos Flag Behavior to 'Enter Operation Enabled' sets the interface Control Word bit 13 'Go To Initial Position' in state 'Ready to Operate' (State: 6), normal operation of this behaviour is to move to the 'Initial position' after an enabling.

4 Motion Command Table

The second and main functionality of the Command Table IO interface SW is accessing the Command table through the X6 inputs. Two different evaluation modes are available at the moment:

- Coded States 0..255 With Settle Time
- Coded States 0..255 With Eval on X6.5

In both modes the table below defines the mapping of the inputs to the Command Table ID bits.

X6 input pin	Command Table ID bit
X6.1	Bit 0
X6.14	Bit 1
X6.2	Bit 2
X6.15	Bit 3
X6.3	Bit 4
X6.16	Bit 5
X6.4	Bit 6
X6.17	Bit 7

In the first mode with the settling time parameter the inputs have to be stable for the settling time (UPID: 2300h) until the command is evaluated.

In the second mode the ID inputs are captured on a rising edge if the input X6.5, the input X6.5 could be filtered (UID: 2301h) and inhibited (UPID 2302h).

5 X6 Output Feedback

The 8 output signals on the X6 connector could be configured for different demands to the feedback. The table below shows the default configuration of the X6 outputs

X6 output pin	UPID	Command Table ID bit
X6.9	2400h	Op. Main State Bit 0
X6.22	2500h	Op. Main State Bit 1
X6.10	2600h	Op. Main State Bit 2
X6.23	2700h	Op. Main State Bit 3
X6.11	2800h	None
X6.24	2900h	Status Word bit 'Motion Active'
X6.12	2A00h	Status Word bit 'In Target Position'
X6.25	2B00h	Status Word bit 'Event Handler Active'

With the first 4 output bits (X6.9, X6.22, X6.10 and X6.22) a direct monitoring of the main state is possible, in this way also a transition to the error state could be detected. The output X6.24 is high if a motion is active, X6.12 is high if no motion is active and the Target position is reached within the configurable limit (UPID 1470h, 147Ch and 1471h). The output X6.25 indicates if Event handler is active for example during a sequence of Motion Commands in the Motion Command Table.

Override Functions for outputs On X6

For the inputs X6.18 and X6.6 Override functions of for the X6 outputs could be defined, means for example if the input On X6.18 is high the outputs On X6 have not the configured mapping but shows the error code.

The table below shows the default configuration of the override function.

X6 input pin	UPID	X6 output Override function
X6.18	2230h	Show error code
X6.6	2240h	None