



Ethernet/IP Interface 4.0

User Manual

This document applies to the following controllers:
E1250-IP-xx
(with Ethernet/IP Interface SW installed)

© 2010 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying,

recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

Note:

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation. NTI AG reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement.

Document version 4.0 / Whp, June 2010

Inhaltsverzeichnis

1	SYSTEM OVERVIEW	4
1.1	REFERENCES	4
2	CONNECTING TO THE ETHERNET/IP NETWORK	5
2.1	PIN ASSIGNMENT OF THE CONNECTORS X17-X18	5
2.2	DEFAULT IP ADDRESS SETTINGS	5
3	SETUP IN THE PLC	6
3.1	RSLINX CLASSIC	6
3.2	LINMOT CONFIGURATION IN THE PLC	8
3.3	GETTING STARTED WITH THE WATCH WINDOW	14
3.3.1	<i>Control Word</i>	15
3.3.2	<i>Motion Command Interface</i>	18
4	ETHERNET/IP PARAMETERS	22
4.1	PARAMETERS	22
5	REALTIME IO DATA MAPPING	24
5.1	DEFAULT O → T AND T → O MAPPING	24
5.1.1	<i>Default O → T Mapping Assembly Instance 32</i>	24
5.1.2	<i>Default T → O Mapping Assembly Instance 16</i>	24
5.2	O → T AND T → O MAPPING WITH CONFIGURATION MODULE	25
5.2.1	<i>Default O → T Mapping Assembly Instance 40</i>	25
5.2.2	<i>Default T → O Mapping Assembly Instance 24</i>	25
5.2.3	<i>PLC Setup of Mapping With Configuration Module</i>	26
5.2.4	<i>Example of reading Parameter RAM value with Configuration Module</i>	27
6	CONTACT ADDRESSES	28

1 System overview

The LinMot Ethernet/IP servo controllers have the following functionalities:

Device Property	Value / Remark
Minimal Ethernet/IP cycle time	1 ms
DHCP -Support	Supported
EDS Support	Not yet supported from AB
IEEE1588 (CIP-Synch)	For 3 rd parties not supported from AB
DLR Support (Device Level Ring Protocol)	No

Ethernet/IP is a real time Ethernet protocol based on the standard Ethernet protocols TCP/IP and UDP/IP.

For further information on Ethernet/IP please visit: <http://www.odva.org>

1.1 References


All User Manuals are distributed with the LinMot-Talk configuration software the newest version could be downloaded from the LinMot homepage in the download section.

Ref	Title	Source
1	User Manual Motion Control SW	www.linmot.com
2	LinMot Servo Controller Configuration over Fieldbus Interfaces SG5	www.linmot.com

2 Connecting to the Ethernet/IP Network


2.1 Pin Assignment of the Connectors X17-X18

The Ethernet/IP connector is a standard RJ45 female connector with a pin assignment as defined by EIA/TIA T568B:

X17 – X18		RealTime Ethernet Connector	
	Pin	Wire color code	Assignment 100BASE-TX
	1	WHT/ORG	Rx+
	2	ORG	Rx-
	3	WHT/GRN	Tx+
	4	BLU	-
	5	WHT/BLU	-
	6	GRN	Tx-
	7	WHT/BRN	-
	8	BRN	-
RJ-45		case	-
		Use standard patch cables (twisted pair, S/UTP, AWG26) for wiring. This type of cable is usually referred to as a "Cat5e-Cable".	

2.2 Default IP Address Settings

The default IP address is 192.168.001.xxx where the last byte xxx is defined via the two Hex-Switches S1 and S2, where S1 sets the high digit and S2 the low digit.

S1, S2:	IP Selectors	
	S1	Bus ID High (0h...Fh)
	S2	Bus ID Low (0h...Fh)




IMPORTANT: The Switch value S1 = 0 and S2 = 0 (factory default setting) acquiring IP address via DHCP is activated instead.

3 Setup in the PLC


The following steps describe the integration of a LinMot Ethernet/IP servo controller in the PLC. In the example an Allen Bradley master PLC is used. RSLinx tool can only be used to see if the device is on the network and under which IP-address it can be accessed. The whole configuration is done in the PLC, which is described in Chapter 3.2.

3.1 RSLinx Classic

In the RSLinx the LinMot device should occur under the defined IP address as “Unrecognized Device”




LinMot device with the IP address 192.168.1.89 in the RSLinx tool




LinMot device properties

3.2 LinMot Configuration in the PLC

The LinMot can be configured in the I/O configuration section, in the Ethernet section as a New Module



Then you have to select in the Communications Module the ETHERNET-MODULE



Under the Module Properties you can define the module specific data:

- Name
- Comm Format in the example a 16 bit Format is chosen!
- IP Address
- Input Assembly instance and size
- Output Assembly Instance and size

Be careful defining these parameters, because only a correct setting will run in the in the Ethernet/IP network. Only the name can be defined freely.

Module Properties: LocalENB (ETHERNET-MODULE 1.1)

General* | Connection | Module Info


Type: ETHERNET-MODULE Generic Ethernet Module
Vendor: Allen-Bradley
Parent: LocalENB
Name: X_Axis
Description:
Comm Format: Data - INT
Address / Host Name:
☒ IP Address: 192 . 168 . 1 . 89
☐ Host Name:
Status: Offline

Connection Parameters


	Assembly Instance:	Size:	
Input:	16	9	(16-bit)
Output:	32	12	(16-bit)
Configuration:	1	0	(8-bit)
Status Input:			
Status Output:			

OK Cancel Apply Help

In the Connection Tab of the Module Properties the desired cycle time is specified in the range between 1ms and 3200ms.




Then the configuration/program can be downloaded and you can change to the online view.



Also Unicast Connection is supported.

If all was set up correctly the LinMot module status should be running



LinMot-Talk1100 - V3.11 Build 20100104

File Search Controller Services Options Window Tools Manuals Help

Unnamed, IP: 192.168.2.4 (DEVELOPER)

Control Panel

Parameters

OS

Motion Control SW

Ethernet/IP Intf

Variables

User Defined

OS SW Operating Hours / Time

OS SW Message/Error

OS SW Trap

OS SW Monitoring

OS SW HW Configuration

OS SW Status

OS SW Debug

IO Config

MC SW Overview

MC SW E1200 Debug

MC SW Motor

MC SW X13 Ext Sensor

MC SW Current Controller

MC SW Control Word

MC SW Status Word

MC SW Warnings

MC SW Phase Search

MC SW Linearizing

MC SW Motion Interface

MC SW Winding

MC SW Capture, Trigger & Mapped Inputs

MC SW VA interpolator

MC SW Curve

MC SW PVT Stream

MC SW Monitoring

MC SW Errors

MC SW Encoder CAM

MC SW Motor Data Sheet

MC SW Command Table

MC SW Force Control

MC Remanent Variables

ControlPanel Tokens

Operating Hour Counter

Ethernet/IP

Ethernet/IP:O->T, T->O config

Ethernet/IP:Debug

Oscilloscopes

Name	Value	RawData	UPID
Connection State	Established	0003h	9056
Originator IP Address	192.168. 1.252		9057
O -> T Connection Type	Point to Point	0002h	9104
O -> T Assembly Instance	20h	20h	9076
O -> T API	10 ms	00002710h	9072
O -> T Timeout	160 ms	00027100h	9075
O -> T Size	30	001Eh	9073
O -> T Sequence Number	561217	00089041h	9074
T -> O Connection Type	Multicast	0001h	9120
T -> O Assembly Instance	10h	10h	9092
T -> O API	10 ms	00002710h	9088
T -> O Size	20	0014h	9089
T -> O Sequence Number	562915	000896E3h	9090
O -> T Cycle Time	10039.9 us	0001882Fh	9112
Minimal O -> T Cycle Time	9778.8 us	00017DFCh	9113
Maximal O -> T Cycle Time	10325.7 us	00019359h	9114

In The LinMot-Talk configuration software the Ethernet/IP connection state can be watched under variables\Ethernet/IP:O ->T, T-> O config. If everything was set up correctly, the connection state should change to established when powered on after a certain time. In this state both counters O → T and T → O should count up depending on the configured period time.

3.3 Getting started with the Watch window

In this section the basics of the LinMot device handling are explained. Instead of programming the LinMot, data it is directly influenced with the watch window. So, for the next steps, map the module input data and output data in the quick watch window as below.

In the following examples it is assumed, that a motor is configured and the power supply is on, and the servo controller is correctly embedded in the Ethernet/IP network.

The screenshot shows the RSLogix 5000 software interface. The main window displays the 'Watch' tab, which lists variables under the 'Current Routine' tab. The variables are organized into a table with columns: Name, Scope, Value, Force Mask, and Description.

Name	Scope	Value	Force Mask	Description
X_Axis:1	Controller	{...}	{...}	
X_Axis:1.Data	Controller	{...}	{...}	
X_Axis:1.Data[0]	Controller	512		
X_Axis:1.Data[1]	Controller	16560		
X_Axis:1.Data[2]	Controller	128		
X_Axis:1.Data[3]	Controller	0		
X_Axis:1.Data[4]	Controller	0		
X_Axis:1.Data[5]	Controller	-24		
X_Axis:1.Data[6]	Controller	-1		
X_Axis:1.Data[7]	Controller	0		
X_Axis:1.Data[8]	Controller	0		
X_Axis:0	Controller	{...}	{...}	
X_Axis:0.Data	Controller	{...}	{...}	
X_Axis:0.Data[0]	Controller	0		
X_Axis:0.Data[1]	Controller	0		
X_Axis:0.Data[2]	Controller	0		
X_Axis:0.Data[3]	Controller	0		
X_Axis:0.Data[4]	Controller	0		
X_Axis:0.Data[5]	Controller	0		
X_Axis:0.Data[6]	Controller	0		
X_Axis:0.Data[7]	Controller	0		
X_Axis:0.Data[8]	Controller	0		
X_Axis:0.Data[9]	Controller	0		
X_Axis:0.Data[10]	Controller	0		
X_Axis:0.Data[11]	Controller	0		

3.3.1 Control Word

The Control Word is mapped to the output data word 0. If setting this value to 1 the “Switch On” bit (Bit 0) of the control word is set

Watch List:	Name	Scope	Value	Force Mask	Description
Current Routine	[-] X_Axis:I	Controller	{...}	{...}	
Quick Watch	[-] X_Axis:I.Data	Controller	{...}	{...}	
	+ X_Axis:I.Data[0]	Controller	2048		
	+ X_Axis:I.Data[1]	Controller	16567		
	+ X_Axis:I.Data[2]	Controller	128		
	+ X_Axis:I.Data[3]	Controller	-51		
	+ X_Axis:I.Data[4]	Controller	-1		
	+ X_Axis:I.Data[5]	Controller	-51		
	+ X_Axis:I.Data[6]	Controller	-1		
	+ X_Axis:I.Data[7]	Controller	-2		
	+ X_Axis:I.Data[8]	Controller	-1		
	[-] X_Axis:O	Controller	{...}	{...}	
	[-] X_Axis:O.Data	Controller	{...}	{...}	
	+ X_Axis:O.Data[0]	Controller	1		
	+ X_Axis:O.Data[1]	Controller	0		
	+ X_Axis:O.Data[2]	Controller	0		
	+ X_Axis:O.Data[3]	Controller	0		
	+ X_Axis:O.Data[4]	Controller	0		
	+ X_Axis:O.Data[5]	Controller	0		
	+ X_Axis:O.Data[6]	Controller	0		
	+ X_Axis:O.Data[7]	Controller	0		
	+ X_Axis:O.Data[8]	Controller	0		
	+ X_Axis:O.Data[9]	Controller	0		
	+ X_Axis:O.Data[10]	Controller	0		
	+ X_Axis:O.Data[11]	Controller	0		

LinMot-Talk1100 - V3.11 Build 20100104

File Search Controller Services Options Window Tools Manuals Help

Unnamed, IP: 192.168.2.4 (DEVELOPER)

Project: Unnamed, IP: 192.168.2.4 (DEVELOPER)

Control Panel Parameters Variables

User Defined

OS SW Operating Hours / Time

OS SW Message/Error

OS SW Trap

OS SW Monitoring

OS SW Hw/ Configuration

OS SW Status

OS SW Debug

IO Config

MC SW Overview

MC SW E1200 Debug

MC SW Motor

MC SW X13 Ext Sensor

MC SW Current Controller

MC SW Control Word

MC SW Status Word

MC SW Warnings

MC SW Phase Search

MC SW Linearizing

MC SW Motion Interface

MC SW Winding

MC SW Capture, Trigger & Mapped Inputs

MC SW VA interpolator

MC SW Curve

MC SW PVT Stream

MC SW Monitoring

MC SW Errors

MC SW Encoder CAM

MC SW Motor Data Sheet

MC SW Command Table

MC SW Force Control

MC Permanent Variables

ControlPanel Tokens

Operating Hour Counter

Ethernet/IP

Ethernet/IP:O>T, T>O config

Control

0: Switch On.....1 Interface

1: Safety Stop.....1 Digital Input X4.12

2: /Quick Stop.....1 Forced by Parameter

3: Enable Operation.....1 Forced by Parameter

4: /Abort.....1 Forced by Parameter

5: /Freeze.....1 Forced by Parameter

6: Go To Position.....0 Interface

7: Error Acknowledge.....0 Interface

8: Jog Move +.....0 Interface

9: Jog Move -.....0 Interface

10: Special Mode.....0 Interface

11: Home.....0 Interface

12: Clearance Check.....0 Interface

13: Go To Initial Position.....0 Interface

14: Linearizing.....0 No Source Specified

15: Phase Search.....0 No Source Specified

Control Word: 003Fh

Override Value

Enable Manual Override

Status

0: Operation Enabled.....1

1: Switch On Active.....1

2: Enable Operation.....1

3: Error.....0

4: Safety Volt. Enable.....1

5: /Quick Stop.....1

6: Switch On Locked.....0

7: Warning.....1

8: Event Handler Active.....0

9: Special Motion Active.....0

10: In Target Position.....0

11: Homed.....0

12: Fatal Error.....0

13: Motion Active.....0

14: Range Indicator 1.....1

15: Range Indicator 2.....0

Status Word: 4087h

Op. Main State: 08h

Op. Sub State: 00h

Monitoring

0: Motor Hot Sensor.....0

1: Motor Short Time Overload.....0

2: Motor Supply Voltage Low.....0

3: Motor Supply Voltage High.....0

4: Position Lag Always.....0

5: Position Lag Standing.....0

6: Controller Hot.....0

7: Motor Not Homed.....1

8: PTC Sensor 1 Hot.....0

9: PTC Sensor 2 Hot.....0

10: RR Hot Calculated.....0

11: Reserved.....0

12: Reserved.....0

13: Reserved.....0

14: Interface Warn Flag.....0

15: Application Warn Flag.....0

Warm Word: 0080h

Logged Error Code: 0000h

Connection Status: Online

Firmware Status: Running

Motor Status: Switched On

Op. State: Operation Enabled

Motor Not Homed

Actual Position: 0.00 mm

Demand Position: -0.01 mm

Force Factor: Motor not homed

Motor Current: 0.00 A

Logic Supply Volt.: 25.46 V

Motor Supply Volt.: 79.69 V

IO Panel

Enable Manual Override

Override Value

Actual Value

X4.12 - Input

X4.11 - Input

X4.10 - Input

X4.9 - Input

X4.8 - Input

X4.7 - Input

X4.6 - Input

X4.5 - Input

X4.4 - Input

X4.3 - Input

Command Category: Most Commonly Used

Command Type: No Operation (0000h)

Count Nibble (Toggle Bits): 0h

Auto Increment Count Nibble

Name	Offs.	Description	Scaled Value	Int. Value (Dec)	Int. Value (Hex)
Header	0	0000h: No Operation	0	0	0000h

Read Command Send Command

This can also be monitored in the LinMot-Talk software.

Setting the control word to 2049 sets also the “Home” bit (Bit 11) in the control word. Wait until the input word 0 “State Var” has the value 2319 (0x090F) Main State 9 (Homing) Sub State 0x0F (Homing finished).

Watch List:	Name	Scope	Value	Force Mask	Descript
Current Routine	X_Axis:I	Controller	{...}	{...}	
Quick Watch	X_Axis:I.Data	Controller	{...}	{...}	
	+ X_Axis:I.Data[0]	Controller	2319		
	+ X_Axis:I.Data[1]	Controller	19511		
	+ X_Axis:I.Data[2]	Controller	0		
	+ X_Axis:I.Data[3]	Controller	0		
	+ X_Axis:I.Data[4]	Controller	0		
	+ X_Axis:I.Data[5]	Controller	-159		
	+ X_Axis:I.Data[6]	Controller	-1		
	+ X_Axis:I.Data[7]	Controller	44		
	+ X_Axis:I.Data[8]	Controller	0		
	X_Axis:O	Controller	{...}	{...}	
	X_Axis:O.Data	Controller	{...}	{...}	
	+ X_Axis:O.Data[0]	Controller	2049		
	+ X_Axis:O.Data[1]	Controller	0		
	+ X_Axis:O.Data[2]	Controller	0		
	+ X_Axis:O.Data[3]	Controller	0		
	+ X_Axis:O.Data[4]	Controller	0		
	+ X_Axis:O.Data[5]	Controller	0		
	+ X_Axis:O.Data[6]	Controller	0		
	+ X_Axis:O.Data[7]	Controller	0		
	+ X_Axis:O.Data[8]	Controller	0		
	+ X_Axis:O.Data[9]	Controller	0		
	+ X_Axis:O.Data[10]	Controller	0		
	+ X_Axis:O.Data[11]	Controller	0		

LinMot-Talk1100 - V3.11 Build 20100104

File Search Controller Services Options Window Tools Manuals Help

Project: Unnamed, IP: 192.168.2.4 (DEVELOPER)

Control Panel Parameters Variables

User Defined

OS SW Operating Hours / Time

OS SW Message/Error

OS SW Trap

OS SW Monitoring

OS SW HW Configuration

OS SW Status

OS SW Debug

IO Config

MC SW Overview

MC SW E1200 Debug

MC SW Motor

MC SW X13 Ext Sensor

MC SW Current Controller

MC SW Control Word

MC SW Status Word

MC SW Warnings

MC SW Phase Search

MC SW Linearizing

MC SW Motion Interface

MC SW Winding

MC SW Capture, Trigger & Mapped Inputs

MC SW VA interpolator

MC SW Curve

MC SW PVT Stream

MC SW Monitoring

MC SW Errors

MC SW Encoder CAM

MC SW Motor Data Sheet

MC SW Command Table

MC SW Force Control

MC Remanent Variables

ControlPanel Tokens

Operating Hour Counter

Ethernet/IP

Ethernet/IP-DLT T.xD.medi

Control

0: Switch On.....1 Interface

1: Safety Volt. Enable.....1 Digital Input X4.12

2: /Quick Stop.....1 Forced by Parameter

3: Enable Operation.....1 Forced by Parameter

4: /Abort.....1 Forced by Parameter

5: /Freeze.....1 Forced by Parameter

6: Go To Position.....0 Interface

7: Error Acknowledge.....0 Interface

8: Jog Move +.....0 Interface

9: Jog Move -.....0 Interface

10: Special Mode.....0 Interface

11: Home.....1 Interface

12: Clearance Check.....0 Interface

13: Go To Initial Position.....0 Interface

14: Linearizing.....0 No Source Specified

15: Phase Search.....0 No Source Specified

Control Word: 083Fh

Override Value

Enable Manual Override

Status

0: Operation Enabled.....1

1: Switch On Active.....0

2: Enable Operation.....1

3: Error.....0

4: Safety Volt. Enable.....1

5: /Quick Stop.....1

6: Switch On Locked.....0

7: Warning.....0

8: Event Handler Active.....0

9: Special Motion Active.....0

10: In Target Position.....1

11: Homed.....1

12: Fatal Error.....0

13: Motion Active.....0

14: Range Indicator 1.....1

15: Range Indicator 2.....0

Status Word: 4C37h

Op. Main State: 09h

Op. Sub State: 0Fh

Monitoring

0: Motor Hot Sensor.....0

1: Motor Short Time Overload.....0

2: Motor Supply Voltage Low.....0

3: Motor Supply Voltage High.....0

4: Position Lag Always.....0

5: Position Lag Standing.....0

6: Controller Hot.....0

7: Motor Not Homed.....0

8: PTC Sensor 1 Hot.....0

9: PTC Sensor 2 Hot.....0

10: RFI Hot Calculated.....0

11: Reserved.....0

12: Reserved.....0

13: Reserved.....0

14: Interface Warn Flag.....0

15: Application Warn Flag.....0

Connection Status: Online

Firmware Status: Running

Motor Status: Switched On

Op. State: Homing

Actual Position: -0.02 mm

Demand Position: 0.00 mm

Force Factor: 100.00 %

Motor Current: 0.04 A

Logic Supply Volt.: 25.46 V

Motor Supply Volt.: 79.69 V

IO Panel

Enable Manual Override

Override Value

Actual Value

X4.12 - Input

X4.11 - Input

X4.10 - Input

X4.9 - Input

X4.8 - Input

X4.7 - Input

X4.6 - Input

X4.5 - Input

X4.4 - Input

X4.3 - Input

Enable Manual Override: ☐ -10 mm -1 mm +1 mm +10 mm

Command Category: Most Commonly Used

Command Type: [No Operation (000h)]

Count Nibble (Toggle Bits): 0h ☐ Auto Increment Count Nibble

Name	Offs.	Description	Scaled Value	Int. Value (Dec)	Int. Value (Hex)
Header	0	000h: No Operation	0	0	0000h

Read Command Send Command

Then the Control Word can be set to 1 again, the controller will change to Main State 8 (Operation Enabled) Sub State 0xC0 (Homed and In Target Position), the corresponding input word 0 has the value 2240.

Watch List:	Name	Scope	Value	Force Mask	Description
Current Routine	- X_Axis:I	Controller	{...}	{...}	
Quick Watch	- X_Axis:I.Data	Controller	{...}	{...}	
	+ X_Axis:I.Data[0]	Controller	2240		
	+ X_Axis:I.Data[1]	Controller	19511		
	+ X_Axis:I.Data[2]	Controller	0		
	+ X_Axis:I.Data[3]	Controller	0		
	+ X_Axis:I.Data[4]	Controller	0		
	+ X_Axis:I.Data[5]	Controller	-156		
	+ X_Axis:I.Data[6]	Controller	-1		
	+ X_Axis:I.Data[7]	Controller	44		
	+ X_Axis:I.Data[8]	Controller	0		
	- X_Axis:O	Controller	{...}	{...}	
	- X_Axis:O.Data	Controller	{...}	{...}	
	+ X_Axis:O.Data[0]	Controller	1		
	+ X_Axis:O.Data[1]	Controller	0		
	+ X_Axis:O.Data[2]	Controller	0		
	+ X_Axis:O.Data[3]	Controller	0		
	+ X_Axis:O.Data[4]	Controller	0		
	+ X_Axis:O.Data[5]	Controller	0		
	+ X_Axis:O.Data[6]	Controller	0		
	+ X_Axis:O.Data[7]	Controller	0		
	+ X_Axis:O.Data[8]	Controller	0		
	+ X_Axis:O.Data[9]	Controller	0		
	+ X_Axis:O.Data[10]	Controller	0		
	+ X_Axis:O.Data[11]	Controller	0		

LinMot-Talk1100 - V3.11 Build 20100104

File Search Controller Services Options Window Tools Manuals Help

Project: Unnamed, IP: 192.168.2.4 (DEVELOPER)

Control Panel Parameters Variables

Control Word: 003Fh

Override Value: Enable Manual Override

IO Panel

Enable Manual Override

Override Value: Actual Value

Command Category: Most Commonly Used

Command Type: No Operation (000h)

Count Nibble (Toggle Bits): 0h

Auto Increment Count Nibble

Name	Offs	Description	Scaled Value	Int. Value (Dec)	Int. Value (Hex)
Header	0	000h: No Operation	0	0	0000h

Read Command Send Command

Monitoring

Connection Status: Online

Firmware Status: Running

Motor Status: Switched On

Op. State: Operation Enabled

Actual Position: -0.02 mm

Demand Position: 0.00 mm

Force Factor: 100.00 %

Motor Current: 0.04 A

Logic Supply Volt: 25.46 V

Motor Supply Volt: 79.69 V

3.3.2 Motion Command Interface

The rest of the output data (O.data[1]..O.data[11]) is mapped to the “Motion Command Interface”

The first word (O.data[1]) is the motion command header, the rest (O.data[1]..O.data[11]) is the command specific motion parameter set. In the next example we will setup a “Predef VAI Go To Pos (020xh)” Motion Command. First we set the target position low word (O.data[2]) to 0 then the target position high word (O.data[3]) to 2 and the motion command header (O.data[1]) to 513 (0201h).

Watch List:	Name	Scope	Value	Force Mask	Description
Current Routine	- X_Axis:1	Controller	{...}	{...}	
Quick Watch	- X_Axis:1.Data	Controller	{...}	{...}	
	+ X_Axis:1.Data[0]	Controller	2241		
	+ X_Axis:1.Data[1]	Controller	3639		
	+ X_Axis:1.Data[2]	Controller	0		
	+ X_Axis:1.Data[3]	Controller	0		
	+ X_Axis:1.Data[4]	Controller	2		
	+ X_Axis:1.Data[5]	Controller	-250		
	+ X_Axis:1.Data[6]	Controller	1		
	+ X_Axis:1.Data[7]	Controller	72		
	+ X_Axis:1.Data[8]	Controller	0		
	- X_Axis:0	Controller	{...}	{...}	
	- X_Axis:0.Data	Controller	{...}	{...}	
	+ X_Axis:0.Data[0]	Controller	1		
	+ X_Axis:0.Data[1]	Controller	513		
	+ X_Axis:0.Data[2]	Controller	0		
	+ X_Axis:0.Data[3]	Controller	2		
	+ X_Axis:0.Data[4]	Controller	0		
	+ X_Axis:0.Data[5]	Controller	0		
	+ X_Axis:0.Data[6]	Controller	0		
	+ X_Axis:0.Data[7]	Controller	0		
	+ X_Axis:0.Data[8]	Controller	0		
	+ X_Axis:0.Data[9]	Controller	0		
	+ X_Axis:0.Data[10]	Controller	0		
	+ X_Axis:0.Data[11]	Controller	0		

LinMot-Talk1100 - V3.11 Build 20100104

File Search Controller Services Options Window Tools Manuals Help

Unamed, IP: 192.168.2.4 (DEVELOPER)

Project

- Unamed, IP: 192.168.2.4 (DEVELOPER)
 - Control Panel
 - Parameters
 - Variables
 - User Defined
 - OS SW Operating Hours / Time
 - OS SW Message/Error
 - OS SW Trap
 - OS SW Monitoring
 - OS SW HW Configuration
 - OS SW Status
 - OS SW Debug
 - IO Config
 - MC SW Overview
 - MC SW E1200 Debug
 - MC SW Motor
 - MC SW X13 Ext Sensor
 - MC SW Current Controller
 - MC SW Control Word
 - MC SW Status Word
 - MC SW Warnings
 - MC SW Phase Search
 - MC SW Linearizing
 - MC SW Motion Interface
 - MC SW Winding
 - MC SW Capture, Trigger & Mapped Inputs
 - MC SW VA interpolator
 - MC SW Curve
 - MC SW PVT Stream
 - MC SW Monitoring
 - MC SW Errors
 - MC SW Encoder CAM
 - MC SW Motor Data Sheet
 - MC SW Command Table
 - MC SW Force Control
 - MC Remanent Variables
 - ControlPanel Tokens
 - Operating Hour Counter
 - Ethernet/IP
 - FilePanel/IP (N-T-T-T-0 conf)

Control

0: Switch On...1 Interface

1: Safety Volt. Enable...1 Digital Input X4.12

2: /Quick Stop...1 Forced by Parameter

3: Enable Operation...1 Forced by Parameter

4: /Abort...1 Forced by Parameter

5: /Freeze...1 Forced by Parameter

6: Go To Position...0 Interface

7: Error Acknowledge...0 Interface

8: Jog Move...0 Interface

9: Jog Move...0 Interface

10: Special Mode...0 Interface

11: Home...0 Interface

12: Clearance Check...0 Interface

13: Go To Initial Position...0 Interface

14: Linearizing...0 No Source Specified

15: Phase Search...0 No Source Specified

Control Word: 003Fh

Override Value

Enable Manual Override

IO Panel

Enable Manual Override

Override Value

Actual Value

X4.12 - Input

X4.11 - Input

X4.10 - Input

X4.9 - Input

X4.8 - Input

X4.7 - Input

X4.6 - Input

X4.5 - Input

X4.4 - Input

X4.3 - Input

Status

0: Operation Enabled...1

1: Switch On Active...1

2: Enable Operation...1

3: Error...0

4: Safety Volt. Enable...1

5: /Quick Stop...1

6: Switch On Locked...0

7: Warning...0

8: Event Handler Active...0

9: Special Motion Active...1

10: In Target Position...1

11: Homed...1

12: Fatal Error...0

13: Motion Active...0

14: Range Indicator 1...0

15: Range Indicator 2...0

Status Word: 0E37h

Op. Main State: 08h

Op. Sub State: CTh

Monitoring

0: Motor Hot Sensor...0

1: Motor Short Time Overload...0

2: Motor Supply Voltage Low...0

3: Motor Supply Voltage High...0

4: Position Lag Always...0

5: Position Lag Standing...0

6: Controller Hot...0

7: Motor Not Homed...0

8: PTC Sensor 1 Hot...0

9: PTC Sensor 2 Hot...0

10: RR Hot Calculated...0

11: Reserved...0

12: Reserved...0

13: Reserved...0

14: Interface Warm Flag...0

15: Application Warm Flag...0

Warm Word: 0000h

Logged Error Code: 0000h

Connection Status: Online

Firmware Status: Running

Motor Status: Switched On

Op. State: Operation Enabled

Actual Position: 13.08 mm

Demand Position: 13.11 mm

Force Factor: 100.00 %

Motor Current: 0.07 A

Logic Supply Volt.: 25.46 V

Motor Supply Volt.: 79.70 V

Enable Manual Override: ☐

-10 mm -1 mm +1 mm +10 mm

Command Category: Most Commonly Used

Command Type: Predef VAI Go To Pos (020xh)

Count Nibble (Toggle Bits): 1h ☐ Auto Increment Count Nibble

Name	Offs.	Description	Scaled Value	Int. Value (Dec)	Int. Value (Hex)
Header	0	020xh: Predef VAI Go To P...	513	513	0201h
1. Par	2	Target Position	13.1072 mm	131072	00020000h

Read Command Send Command

Press the “read Command” button and you see the command which was sent.

We will use the same command to move back to 0mm. Change the target position high word to 0. Then change the count nibble in the motion command header to 0.

Watch List:	Name	Scope	Value	Force Mask	Description
Current Routine	- X_Axis:I	Controller	{...}	{...}	
Quick Watch	- X_Axis:I.Data	Controller	{...}	{...}	
	+ X_Axis:I.Data[0]	Controller	2240		
	+ X_Axis:I.Data[1]	Controller	20023		
	+ X_Axis:I.Data[2]	Controller	0		
	+ X_Axis:I.Data[3]	Controller	0		
	+ X_Axis:I.Data[4]	Controller	0		
	+ X_Axis:I.Data[5]	Controller	1205		
	+ X_Axis:I.Data[6]	Controller	0		
	+ X_Axis:I.Data[7]	Controller	-329		
	+ X_Axis:I.Data[8]	Controller	-1		
	- X_Axis:O	Controller	{...}	{...}	
	- X_Axis:O.Data	Controller	{...}	{...}	
	+ X_Axis:O.Data[0]	Controller	1		
	+ X_Axis:O.Data[1]	Controller	512		
	+ X_Axis:O.Data[2]	Controller	0		
	+ X_Axis:O.Data[3]	Controller	0		
	+ X_Axis:O.Data[4]	Controller	0		
	+ X_Axis:O.Data[5]	Controller	0		
	+ X_Axis:O.Data[6]	Controller	0		
	+ X_Axis:O.Data[7]	Controller	0		
	+ X_Axis:O.Data[8]	Controller	0		
	+ X_Axis:O.Data[9]	Controller	0		
	+ X_Axis:O.Data[10]	Controller	0		
	+ X_Axis:O.Data[11]	Controller	0		

LinMot-Talk1100 - V3.11 Build 20100104

File Search Controller Services Options Window Tools Manuals Help

Unsaved, IP: 192.168.2.4 (DEVELOPER)

Project: Unnamed, IP: 192.168.2.4 (DEVELOPER)

Control Panel Parameters Variables

Control Word: 003Fh

Override Value

Enable Manual Override

IO Panel

Override Value

Actual Value

Enable Manual Override

Command Category: Most Commonly Used

Command Type: Predel VAI Go To Pos (020h)

Count Nibble (Toggle Bits): 0h

Auto Increment Count Nibble

Name	Offs	Description	Scaled Value	Int. Value (Dec)	Int. Value (Hex)
Header	0	020h: Predel VAI Go To P...	512	512	0200h
1. Par	2	Target Position	0 mm	0	00000000h

Read Command Send Command

Monitoring

Connection Status: Online

Firmware Status: Running

Motor Status: Switched On

Op. State: Operation Enabled

Actual Position: 0.12 mm

Demand Position: 0.00 mm


Force Factor: 100.00 %

Motor Current: -0.33 A


Logic Supply Volt: 25.46 V

Motor Supply Volt: 79.70 V

In the next example we are going to use the most common motion command “VAI Go To Pos (010xh)”. In this example we define the motion command in the control panel first.



Then we put the same values in the watch window. First the motion parameters then the motion header!



Moving back to 0mm with the same motion command and the same parameters, just set the target position to 0 (O.Data[2] and O.Data[3]) then change the count nibble in the motion command header to 2 for example.

Watch List:	Name	Scope	Value	Force Mask	Description
Current Routine	[-] X_Axis:I	Controller	{...}	{...}	
Quick Watch	[-] X_Axis:I.Data	Controller	{...}	{...}	
	+ X_Axis:I.Data[0]	Controller	2242		
	+ X_Axis:I.Data[1]	Controller	20023		
	+ X_Axis:I.Data[2]	Controller	0		
	+ X_Axis:I.Data[3]	Controller	0		
	+ X_Axis:I.Data[4]	Controller	0		
	+ X_Axis:I.Data[5]	Controller	1543		
	+ X_Axis:I.Data[6]	Controller	0		
	+ X_Axis:I.Data[7]	Controller	-448		
	+ X_Axis:I.Data[8]	Controller	-1		
	[-] X_Axis:O	Controller	{...}	{...}	
	[-] X_Axis:O.Data	Controller	{...}	{...}	
	+ X_Axis:O.Data[0]	Controller	1		
	+ X_Axis:O.Data[1]	Controller	258		
	+ X_Axis:O.Data[2]	Controller	0		
	+ X_Axis:O.Data[3]	Controller	0		
	+ X_Axis:O.Data[4]	Controller	16960		
	+ X_Axis:O.Data[5]	Controller	15		
	+ X_Axis:O.Data[6]	Controller	-31072		
	+ X_Axis:O.Data[7]	Controller	1		
	+ X_Axis:O.Data[8]	Controller	3392		
	+ X_Axis:O.Data[9]	Controller	3		
	+ X_Axis:O.Data[10]	Controller	0		
	+ X_Axis:O.Data[11]	Controller	0		

LinMot-Talk1100 - V3.11 Build 20100104

File Search Controller Services Options Window Tools Manuals Help

Unnamed, IP: 192.168.2.4 (DEVELOPER)

Project: Unnamed, IP: 192.168.2.4 (DEVELOPER)

Control Panel

Parameters

User Defined

OS SW Operating Hours / Time

OS SW Trap

OS SW Monitoring

OS SW HW Configuration

OS SW Status

OS SW Debug

IO Config

MC SW Overview

MC SW E1200 Debug

MC SW Motor

MC SW X13 Ext Sensor

MC SW Current Controller

MC SW Control Word

MC SW Status Word

MC SW Warnings

MC SW Phase Search

MC SW Linearizing

MC SW Motion Interface

MC SW Winding

MC SW Capture, Trigger & Mapped Inputs

MC SW VA interpolator

MC SW Curve

MC SW PVT Stream

MC SW Monitoring

MC SW Errors

MC SW Encoder CAM

MC SW Motor Data Sheet

MC SW Command Table

MC SW Force Control

MC Remanent Variables

ControlPanel Tokens

Operating Hour Counter

Ethernet/IP

Ethernet/IP-D>T, T>D config

Ethernet/IP-D>T, T>D config

Control

0: Switch On.....1 Interface

1: Safety Volt. Enable.....1 Digital Input X4.12

2: /Quick Stop.....1 Forced by Parameter

3: Enable Operation.....1 Forced by Parameter

4: /Abort.....1 Forced by Parameter

5: Freeze.....1 Forced by Parameter

6: Go To Position.....0 Interface

7: Error Acknowledge.....0 Interface

8: Jog Move +.....0 Interface

9: Jog Move -.....0 Interface

10: Special Mode.....0 Interface

11: Home.....0 Interface

12: Clearance Check.....0 Interface

13: Go To Initial Position.....0 Interface

14: Linearizing.....0 No Source Specified

15: Phase Search.....0 No Source Specified

Control Word: 003Fh

Override Value

Enable Manual Override

IO Panel

Enable Manual Override

Override Value

Actual Value

X4.12 - Input

X4.11 - Input

X4.10 - Input

X4.9 - Input

X4.8 - Input

X4.7 - Input

X4.6 - Input

X4.5 - Input

X4.4 - Input

X4.3 - Input

Status

0: Operation Enabled.....1

1: Switch On Active.....1

2: Enable Operation.....1

3: Error.....0

4: Safety Volt. Enable.....1

5: /Quick Stop.....1

6: Switch On Locked.....0

7: Warning.....0

8: Event Handler Active.....0

9: Special Motion Active.....1

10: In Target Position.....1

11: Home.....1

12: Fatal Error.....0

13: Motion Active.....0

14: Range Indicator 1.....1

15: Range Indicator 2.....0

Status Word: 4E37h

Warn Word: 0000h

Op. Main State: 00h

Op. Sub State: C2h

Monitoring

Connection Status: Online

Firmware Status: Running

Motor Status: Switched On

Op. State: Operation Enabled

Actual Position: 0.16 mm

Demand Position: 0.00 mm

Force Factor: 100.00 %

Motor Current: -0.45 A

Logic Supply Volt.: 25.46 V

Motor Supply Volt.: 79.70 V

Enable Manual Override: ☐ -10 mm -1 mm +1 mm +10 mm

Command Category: Most Commonly Used

Command Type: VAI Go To Pos (0104h)

Count Nibble (Toggle Bits): 2h ☐ Auto Increment Count Nibble

Name	Offs.	Description	Scaled Value	Int. Value (Dec)	Int. Value (Hex)
Header	0	0104h: VAI Go To Pos	258	258	0103h
1. Par	2	Target Position	0 mm	0	00000000h
2. Par	6	Maximal Velocity	1 m/s	1000000	000F4240h
3. Par	10	Acceleration	1 m/s ²	100000	000186A0h
4. Par	14	Deceleration	2 m/s ²	200000	00030D40h

Read Command Send Command

4 Ethernet/IP Parameters

4.1 Parameters

The Ethernet/IP interface has an additional parameter tree branch (Parameters → Ethernet/IP Intf), which can be configured with the distributed LinMot-Talk software. With these parameters, the Ethernet/IP communication parameters can be configured. The LinMot-Talk software can be downloaded from <http://www.linmot.com> under the section download, software & manuals.

Ethernet/IP Intf\ Dis-/Enable

With the Dis-/Enable parameter the LinMot servo controller can be run without the Ethernet Ethernet/IP interface going online. So in a first step the system can be configured and run without any bus connection.

POWERLINK\ Dis-/Enable	
Disable	Servo controller runs without Ethernet/IP.
Enable	Servo controller runs with Ethernet/IP connection.



IMPORTANT: If the Ethernet/IP interface is disabled, the integrated Ethernet/IP switch is not powered! No messages will be sent to other devices connected to the Ethernet-Network via the LinMot servo controller.

Ethernet/IP Intf\Ethernet Configuration\ IP Configuration Mode

This parameter defines how the IP address is assigned.

Ethernet/IP Intf\Ethernet Configuraton\ IP configuration Mode	
DHCP	IP address is acquired via DHCP mechanism.
Static by IP Configuration	IP address is defined with parameters only.
Static with Hex Switches S1 and S2 (DHCP)	IP address is defined with parameters and the last byte is defined with the value of the HEX switches S1 and S2. The default IP address setting is 192.168.001.xxx (xxx stands for the value of the Hex switches S1 and S2)



IMPORTANT: The Switch value **S1 = 0** and **S2 = 0** (factory default setting) acquiring IP address via **DHCP** is activated instead.

Ethernet/IP Intf\Ethernet Configuraton\ IP Configuration

In this section the paremeters for the IP address netmask, default gateway and multicast IP address are located.

Ethernet/IP Intf\Ethernet Configuraton\ IP Configuration	
IP address 1st Byte	Highest byte of IP address
IP address 2nd Byte	Mid high byte of IP address
IP address 3rd Byte	Mid low byte of IP address
IP address 4th Byte	Lowest byte of IP address
Netmask 1st Byte	Highest byte of Netmask
Netmask 2nd Byte	Mid high byte of Netmask
Netmask 3rd Byte	Mid low byte of Netmask
Netmask 4th Byte	Lowest byte of Netmask
Default Gateway 1st Byte	Highest byte of Default Gateway
Default Gateway 2nd Byte	Mid high byte of Default Gateway
Default Gateway 3rd Byte	Mid low byte of Default Gateway
Default Gateway 4th Byte	Lowest byte of Default Gateway

5 Realtime IO Data Mapping

If you want to control the LinMot device just over the **Control Word** and the **Motion Command Interface** it is sufficient to use the mapping described in Chapter 5. The different mappings over different instances are selected in the assembly class.

5.1 Default O → T and T → O Mapping

5.1.1 Default O → T Mapping Assembly Instance 32

In this real time IO mapping the 16 bit control word, the 16 bit motion command header and the motion command parameters are exchanged. The size of this mapping is 24 bytes or **12 words**. The AB generic Ethernet module adds another 6 bytes (status and counts) so the real exchanged size is 30 bytes.

Assembly Class Instance 32		
Byte Offset	Description	Size / Type
00h	MC SW ControlWord	Uint16 / Bit coded
02h	MC SW MotionCommandHeader	Uint16 / 12Bit Command 4Bit count nibble
04h	MC SW MotionCommandPar Bytes 00..03	Uint32 / Command specific
08h	MC SW MotionCommandPar Bytes 04..07	Uint32 / Command specific
0Ch	MC SW MotionCommandPar Bytes 08..11	Uint32 / Command specific
10h	MC SW MotionCommandPar Bytes 12..15	Uint32 / Command specific
14h	MC SW MotionCommandPar Bytes 16..19	Uint32 / Command specific

5.1.2 Default T → O Mapping Assembly Instance 16

In this real time IO Mapping the StateVar for the main state machine and several other helpful data are exchanged. The size of this mapping is 18 bytes or **9 words**. For the AB generic Ethernet module another 2 bytes (Status and counts) are added, so the real exchanged size is 20 bytes.

Assembly Class Instance 16		
Byte Offset	Description	Size / Type
00h	MC SW StateVar	Uint16 / coded state depending
02h	MC SW StatusWord	Uint16 / Bit coded
04h	MC SW WarnWord	Uint16 / Bit coded
06h	MC SW DemandPosition	Int32 / Position [100nm]
0Ah	MC SW ActualPosition	Int32 / Position [100nm]
0Eh	MC SW DemandCurrent	Int32 / Current [1mA]

For the configuration in PLC of this data refer to chapter 3.2 of this manual.

5.2 O → T and T → O Mapping With Configuration Module

With this real time IO configuration, an additional configuration module is mapped into the IO data communication. The functionality of this module is same for the different fieldbus interfaces. For this reason, the functionality is described in documentation [2] "Controller Configuration over Fieldbus".

5.2.1 Default O → T Mapping Assembly Instance 40

In this real time IO Mapping the 16 bit control word the 16 bit motion command header and motion command parameters are exchanged. The size of this mapping is 32 bytes or **16 words**. The AB generic Ethernet module adds another 6 bytes (Status and counts) so the real exchanged size is 38 bytes.

Assembly Class Instance 40		
Byte Offset	Description	Size / Type
00h	MC SW ControlWord	Uint16 / Bit coded
02h	MC SW MotionCommandHeader	Uint16 / 12Bit Command 4Bit count nibble
04h	MC SW MotionCommandPar Bytes 00..03	Uint32 / Command specific
08h	MC SW MotionCommandPar Bytes 04..07	Uint32 / Command specific
0Ch	MC SW MotionCommandPar Bytes 08..11	Uint32 / Command specific
10h	MC SW MotionCommandPar Bytes 12..15	Uint32 / Command specific
14h	MC SW MotionCommandPar Bytes 16..19	Uint32 / Command specific
18h	Cfg Module Control Word	Uint16
1Ah	Cfg Module Index/..	Uint16
2Ch	Cfg Module Value/..	Uint32/Sint32

5.2.2 Default T → O Mapping Assembly Instance 24

In this real time IO mapping the StateVar for the main state machine and several other helpful data are exchanged. The size of this mapping is 26 bytes or 13 **words**. For the AB generic Ethernet module another 2 bytes (Status and counts) are added, so the real exchanged size is 28 bytes.

Assembly Class Instance 24		
Byte Offset	Description	Size / Type
00h	MC SW StateVar	Uint16 / coded state depending
02h	MC SW StatusWord	Uint16 / Bit coded
04h	MC SW WarnWord	Uint16 / Bit coded
06h	MC SW DemandPosition	Int32 / Position [100nm]
0Ah	MC SW ActualPosition	Int32 / Position [100nm]
0Eh	MC SW DemandCurrent	Int32 / Current [1mA]
12h	Cfg Module Status Word	Uint16
14h	Cfg Module Index/..	Uint16
16h	Cfg Module Value/..	Uint32/Sint32

In the PLC this is configured as followed:

5.2.3 PLC Setup of Mapping With Configuration Module

The screenshot shows the 'Module Properties: ENIP_1 (ETHERNET-MODULE 1.1)' dialog box. The 'General' tab is selected. The fields are as follows:

- Type: ETHERNET-MODULE Generic Ethernet Module
- Vendor: Allen-Bradley
- Parent: ENIP_1
- Name: X_Axis1
- Description: (empty text box)
- Comm Format: Data - INT
- Address / Host Name:
 - ☒ IP Address: 192 . 168 . 1 . 89
 - ☐ Host Name: (empty text box)

The 'Connection Parameters' section is also visible, showing the following settings:

	Assembly Instance:	Size:	
Input:	24	13	(16-bit)
Output:	40	16	(16-bit)
Configuration:	1	0	(8-bit)
Status Input:			
Status Output:			

At the bottom, the status is 'Offline'. Buttons for OK, Cancel, Apply, and Help are present.

Configuration of LinMot Axis with additional Configuration Module (4Word Input and 4 Word Output direction).

5.2.4 Example of reading Parameter RAM value with Configuration Module

Reading RAM Value (0x1101 = 4353; X_Axis1:O.Data[12]) P Gain Position Control Parameter Set A (UPID5026; X_Axis1:O.Data[13]) the result in this example is 15 (X_Axis1:I.Data[11] and X_Axis1:I.Data[12]). The data in the response is valid as soon the count nibble value in the response state (X_Axis1:I.Data[9]) changes to the same value as in the control Word (X_Axis1:O.Data[12]).

Watch					
Quick Watch		Enter Quick Watch List Name...			
Name	Scope	Value	Force Mask	Description	
X_Axis1:O	Controller	{...}	{...}		
X_Axis1:O.Data	Controller	{...}	{...}		
X_Axis1:O.Data[0]	Controller	63			
X_Axis1:O.Data[1]	Controller	514			
X_Axis1:O.Data[2]	Controller	0			
X_Axis1:O.Data[3]	Controller	12			
X_Axis1:O.Data[4]	Controller	0			
X_Axis1:O.Data[5]	Controller	0			
X_Axis1:O.Data[6]	Controller	0			
X_Axis1:O.Data[7]	Controller	0			
X_Axis1:O.Data[8]	Controller	0			
X_Axis1:O.Data[9]	Controller	0			
X_Axis1:O.Data[10]	Controller	0			
X_Axis1:O.Data[11]	Controller	0			
X_Axis1:O.Data[12]	Controller	4353			
X_Axis1:O.Data[13]	Controller	5026			
X_Axis1:O.Data[14]	Controller	0			
X_Axis1:O.Data[15]	Controller	0			
X_Axis1:I.Data	Controller	{...}	{...}		
X_Axis1:I.Data[0]	Controller	2242			
X_Axis1:I.Data[1]	Controller	3127			
X_Axis1:I.Data[2]	Controller	0			
X_Axis1:I.Data[3]	Controller	0			
X_Axis1:I.Data[4]	Controller	12			
X_Axis1:I.Data[5]	Controller	-193			
X_Axis1:I.Data[6]	Controller	11			
X_Axis1:I.Data[7]	Controller	14			
X_Axis1:I.Data[8]	Controller	0			
X_Axis1:I.Data[9]	Controller	1			
X_Axis1:I.Data[10]	Controller	5026			
X_Axis1:I.Data[11]	Controller	15			
X_Axis1:I.Data[12]	Controller	0			

6 Contact Addresses

SWITZERLAND

NTI AG / LinMot
Haerdlistr. 15
CH-8957 Spreitenbach

Sales and Administration: +41-(0)56-419 91 91
office@linmot.com

Tech. Support: +41-(0)56-544 71 00
support@linmot.com

Tech. Support (Skype) : [skype:support.linmot](https://www.skype.com/user/linmot)

Fax: +41-(0)56-419 91 92
Web: <http://www.linmot.com>

USA

LinMot, Inc.
5750 Townline Road
Elkhorn, WI 53121

Sales and Administration: 877-546-3270
262-743-2555

Tech. Support: 877-804-0718
262-743-1284

Fax: 800-463-8708
262-723-6688

E-Mail: us-sales@linmot.com
Web: <http://www.linmot-usa.com>

Please visit <http://www.linmot.com> to find the distributor closest to you.

Smart solutions are...

